CamOne infinity
Module WiFi

Manuel d'utilisation

Lire attentivement ce manuel avant d'utiliser le module WiFi!



Vers.:1.0

Safety advice

WARNING:

Follow these instruction to prevent damage of the unit:

- DO NOT USE UNPROTECTED IF RAIN OR WATER. PREVENT CONTACT WITH ANY KIND OF LIQUIDS
- USE RECOMMENDED ACCESSORIES ONLY
- DO NOT DISASSEMBLE
- THERE ARE NO PARTS AT THE INSIDE THAT NEED TO ME MAINTAINED
- REPAIRS SHOULD BE MADE BY QUALIFIED PERSONNEL ONLY

SERVICE & SUPPORT

ACME the game company GmbH
Boikweg 24

33129 Delbrück
Germany

Tel.: +49 2944 97 383 0

service@camonetec.com
or
http://www.CamOneTec.com

WARNING LIPO BATTERY

- Mishandling the battery may occur explosion, fire and smoke including damage of health or goods. It will also reduce battery performance.
- Never charge a damaged LiPo battery pack.
- Stop charging if the LiPo battery pack is getting deformed (blown up).
- Charge and store the LiPo battery pack at a temperature of 0℃ to 40℃ – avoid a temperature higher than 50℃ when discharging.
- Do not shortcut – Risk of explosion and fire!

CE Declaration

Herewith we declare that this item is in accordance with the essential requirements and other relevant regulations of the directive 2004/108/EC. A copy of the original declaration of conformity can be obtained at the address above.



This product uses LiPo batteries. LiPo batteries are recyclable, and a valuable resource. To dispose of the battery, remove it and take it to a resource recovery facility.



WEEE Reg. Nr.: DE64989527

Information for disposal of crossed Bin marked products

This symbol is marked on a product or packaging, it means that the product including the batteries must not be disposed of with your general household waste. Only discard electrical/electronic items in separate collection schemes, which cater for the recovery and recycling of materials contained within. Your co-operation is vital to ensure the success of these schemes and for the protection of the environment.

ATTENTION!
The privacy of others is protected by law and should be taboo. The recording of third party can be an illegal act. You are responsible for your acting.

Index

Contenu de la boite

Assurez-vous que le produit est complet avant de commencer à l'utiliser!

1x Module WiFi CamOne infinity

Notice

CamOne infinity
Module WiFi

Prenez le contrôle de votre CamOne infinity via votre smartphone ou votre tablette (IOS – Android bientôt disponible) et appréciez de pouvoir visionner vos vidéos en live sur une distance de 10 mètres. Vous pourrez également via l'application disponible, prendre des photos ou démarrer vos enregistrements vidéo.

Points forts

- Visualisation en direct
- Contrôle de toutes les fonctions du menu
- Facile à monter
- Portée jusqu'à 120m

Conseil

La portée peut être réduite en présence d'autres réseaux wifi.

Information légale

Il est possible que certains systèmes en 2.4 GHz RC soient perturbés par la présence du module WiFi. Assurez-vous de ne pas déborder sur les fréquences en 2.4GHz d'autres utilisateurs.

Spécifications

Taille:	**49 x 42 x 24mm**
Poids:	**75g**
Portée:	**jusqu'à 120m**
Température d'utilisation:	**0° C ~ +50° C**
Montage:	**Via le tripode**
Ports:	**OCB (Open Connector Board)** **Mini-USB**


Procédure de mise en marche

Fixer votre CamOne infinity au module WiFi à l'aide du filetage tripode. Assurez-vous lors de la fixation qu'il n'y a pas de poussière entre le module wifi et la caméra. A présent munissez—vous de votre smartphone et procédez comme indiqué :

1. Télécharger l'application „Cam One“ sur le store.
2. Allumer la caméra.
3. Maintenez enfoncé le bouton du module wifi jusqu'à ce que le témoin LED bleu clignote.
4. Sélectionner dans le menu de votre smartphone "réglage »




5. Affichez les réseaux disponibles.



6. Sélectionner le réseau „CamOne“



7. Une fois dans l’application CamOne les identifiants de connexion par défaut sont „Admin“, et le mot de passe „Admin“. Confirmer en cliquant sur „Login“.



8. Pour un accès invité, les identifiants sont „Guest / guest“

Une vidéo explicative est disponible sur notre site on www.CamOneTec.com

Vue d‘ensemble

Photo sauvegardée Vidéo sauvegardée Niveau de batterie

accès à la caméra

Réglage WiFi

Sélection de la bande du WiFi

Eclairage on/ off

menu/réglage

lecture Mode photo

Mode Vidéo